


Instructions


We recommend using the 3P 3P Filter Collector with Push-Fit Connector Kit for Sealed Tanks to fill the rainwater tank. The Filter Collector is available in three colours: Black, Grey and Brown. (Code: 20008*0ST).



Where the water butt cannot be located within 30 cm of the down pipe, longer Long Link Kits are available online (Art. No. 9000123ST to ST5).



a)




b)

5. Installing the Wall Bracket (optional)


- A) Locate the correct position.
- B) Mark the position and drill.
- C) Attach the bracket to the tank using the nut and bolt supplied.
- D) Attach the bracket to the wall using the screw supplied.


Note: You may need to use alternative fittings depending on your wall type. If in doubt, consult a professional.

It is possible to connect two or more tanks together and even to form an above-ground rainwater system. Use the 250mm 3P Tank to Tank Connection Set (9000326), and consult your supplier if you have any queries or wish to purchase further accessories.



The 3P Wall Tank is delivered with a Kit including a optional wall bracket. To fill the Wall Tank, we recommend using the 3P Filter Collector with Push Fit for Sealed Tank Kit (Code: 20008*0ST). **If in any doubt during installation, please consult a professional tradesperson.**





1. Setting Up

Site the Wall Tank on a firm, level surface, near to the downpipe. Siting on soft or uneven ground can cause deformation of the tank over the long term.

When the tank is full is must not touch your wall or any other tanks at any point. Therefore, before filling, position the tank at least 50mm away from the wall and other tanks. This will allow the Wall Tank walls to naturally flex all around as it is filled with water.

Once the Wall Tank is full, check that the Tank is not touching your wall at any point. Reposition as necessary.

2. Connection to the Downpipe

The recommended filter/diverter is the 3P Filter Collector with Push-Fit Connection for Sealed Tanks. Code 2000840ST.

If you have another diverter, please refer to the instructions for your selected downpipe filter.

For the 3P Filter Collector with Push-Fit Connection for Sealed Tanks

Locate the area to form a hole for connecting the downpipe filter or diverter.

The centre of the hole needs to be at least 9cm from the top of the tank and 9cm from a side. This is to allow the grommet to make a good seal on flat surface on the inside of the Tank.

Choose the **44mm** holesaw. Taking care to select the correct saw size.

Double check sizes before drilling.



2. Continued. If in doubt, consult a professional.

Insert the supplied grommet into the hole and ensure that a the inside of the grommet fits neatly onto the inside of the tank. **This is important** because the water tight seal is made on the inside of the tank. Use a finger to feel the seal inside the tank and adjust the seal as required.

Push the Hose into the grommet (washing-up liquid or silicone grease will help ease this) and onto the outlet of the 3P Filter Collector.


3. Connecting the tap

There is a 3/4" BSP thread at approx. 30cm above tank base to connect a tap or other 3/4" BSP fitting. Unscrew the bung and screw in a tap. Take care not to over tighten the tap. Screw the bung into the drain down point.

When using with a metal tap, wrap about 5 to 7 layers of PTFE tape around the thread of the tap to create a more watertight seal and to allow the tap to sit in the correct position.

4. Collecting Water

The side ports can be used to drain down tanks, or to form a system of interconnected tanks. See Step 7.



4. Winter Care Precautions

During extremely cold winters, where daytime temperatures are below zero for several days, it is wise to ensure that the tank is only about 2/3rd's full and the water supply turned off. This will prevent the frozen water from expanding and damaging the tank.

*** Top Tip!** Before filling with water, check the drain-down points are fully tightened. They may just need a ¼ turn. A 2p or 50p piece is the perfect tool if you don't have the right sized screwdriver.